

# Installation Manual



KONGSBERG

## SpotTrack

Relative positioning system

Fanbeam replacement







KONGSBERG

# ***SpotTrack*** ***Relative positioning system***

## ***Installation Manual***

## Document history

Document number: Spot-D-Inst_Fan / Revision 8.0		
Rev. 8.0	March 2021	Modified section "Setting the parameters for network communication". Added message Fanbeam MDL without checksum. Minor changes.

## Copyright

©Kongsberg Seatex AS

*All rights reserved. No part of this work covered by the copyright hereon may be reproduced or otherwise copied without prior permission from Kongsberg Seatex AS.*

## Note

*The information contained in this document remains the sole property of Kongsberg Seatex AS. No part of this document may be copied or reproduced in any form or by any means, and the information contained within it is not to be communicated to a third party, without the prior written consent of Kongsberg Seatex AS.*

*Kongsberg Seatex AS endeavours to ensure that all information in this document is correct and fairly stated, but does not accept liability for any errors or omissions.*

## Warning

*The equipment to which this manual applies must only be used for the purpose for which it was designed. Improper use or maintenance may cause damage to the equipment and/or injury to personnel. The user must be familiar with the contents of the appropriate manuals before attempting to operate or work on the equipment.*

*Kongsberg Seatex disclaims any responsibility for damage or injury caused by improper installation, use or maintenance of the equipment.*

## Comments

To assist us in making improvements to the product and to this manual, we welcome comments and constructive criticism.

e-mail: [km.seatex@km.kongsberg.com](mailto:km.seatex@km.kongsberg.com)

## Table of contents

<b>ABOUT THIS MANUAL .....</b>	<b>7</b>
<b>SPOTTRACK .....</b>	<b>8</b>
System description .....	8
System diagram .....	8
System units .....	10
Sensor Unit .....	10
Junction box (field) .....	10
Junction box (inhouse) .....	10
Control Unit .....	10
SpotTrack accessories .....	11
Scope of supply .....	12
Standard parts provided .....	12
Additional required items .....	13
Product restrictions .....	13
Restrictions in guarantee .....	13
Safety regulations .....	13
Product labels .....	14
Label under the sensor cover .....	14
Labels on the sensor cover .....	14
Support information .....	15
<b>PREPARATIONS .....</b>	<b>16</b>
Installation drawings .....	16
Necessary tools and equipment .....	16
Worker skills .....	16
Location of the system parts .....	17
Sensor Unit .....	17
Junction box (field) .....	17
Junction box (inhouse) .....	18
Control unit .....	18
Monitor .....	18
Reflectors .....	19
Sensor Unit reference point .....	19
Measuring the mounting bracket orientation .....	20
Measuring the mounting bracket location .....	21
Rack requirements .....	21
<b>INSTALLING THE SENSOR UNIT .....</b>	<b>22</b>
Installing the horizontal mounting bracket and the Sensor Unit .....	22
Installing the junction box (field) .....	24

Installing the junction box (inhouse).....	26
Cables .....	27
Cable from Sensor Unit to junction box (field).....	27
Sensor Unit to junction box (field) cable wiring .....	27
Cable from junction box (field) to Fanbeam power supply.....	28
Cable from junction box (field) to junction box (inhouse).....	29
Cable from junction box (inhouse) to Control Unit .....	29
Connecting the junction box (field) to ground .....	29
<b>INSTALLING THE SINGLE PRISM .....</b>	<b>30</b>
<b>INSTALLING THE PRISM CLUSTER .....</b>	<b>32</b>
<b>INSTALLING THE CONTROL UNIT.....</b>	<b>34</b>
Installing the Control Unit in the rack.....	34
Interfaces .....	35
Front interfaces Control Unit .....	35
LED indicators Control Unit.....	35
Rear interfaces Control Unit .....	36
Cables .....	37
Cable from junction box (inhouse) to Control Unit .....	37
Cable from Control Unit to DP .....	37
Cable specifications .....	37
Serial cable from Control Unit to DP wiring .....	37
<b>INSTALLING THE MONITOR .....</b>	<b>39</b>
Installing a standard monitor .....	39
Installing a touch screen monitor .....	39
<b>INTERFACING TO MRU .....</b>	<b>41</b>
4 <sup>th</sup> generation MRU settings .....	41
5 <sup>th</sup> generation MRU settings .....	42
<b>CABLE LAYOUT AND INTERCONNECTIONS .....</b>	<b>45</b>
Cable plan.....	45
List of cables .....	45
<b>CONFIGURATION .....</b>	<b>47</b>
Setting the mounting bracket parameters .....	48
Setting the blind zone .....	49
Setting the sensor search area.....	50
Setting up the DP interface.....	51
Setting up the MRU.....	52
Setting up the display .....	52
Selecting Radar view orientation.....	52
Selecting measurement type .....	53

Selecting measurement unit .....	53
Setting the parameters for network communication.....	54
Setting the SpotTrack sensor IP address.....	54
Connecting the Control Unit to the SpotTrack sensor .....	55
Setting up the Control Unit for remote connection.....	56
Setting vessel shape and vessel dimensions .....	56
Entering vessel name and MMSI.....	56
Entering vessel dimensions.....	57
Verifying data communication .....	57
Displaying sensor raw data .....	57
Checking the system functionality .....	57
Checking the sensor serial number, product and software version .....	58
Replacing or moving the sensor .....	58
Automatic logging.....	59
Changing the log length .....	59
<b>DRAWINGS .....</b>	<b>60</b>
Sensor Unit dimensions.....	61
Mounting bracket, horizontal, dimensions .....	62
Junction box (field) dimensions .....	64
Junction box (inhouse) dimensions .....	65
Control Unit dimensions .....	66
Prism cluster dimensions.....	67
Single prism holder dimensions .....	69
SpotTrack system drawing .....	71
<b>TECHNICAL SPECIFICATIONS .....</b>	<b>72</b>
Performance specifications.....	72
Weights and outline dimensions .....	72
Sensor Unit .....	72
Control Unit .....	73
Junction box (field).....	73
Junction box (inhouse) .....	73
Power specifications .....	73
Sensor Unit .....	73
Control Unit .....	74
Junction box (field).....	74
Junction box (inhouse) .....	74
Environmental specifications .....	74
Sensor Unit .....	74
Control Unit .....	74
Junction box .....	75
Cable specifications.....	75

External interfaces .....	76
Sensor Unit .....	76
Control Unit .....	76
Product safety specifications .....	76
Sensor Unit .....	76
Control Unit .....	76
Compass safe distance .....	76
Telegram types.....	77
SpotTrack message .....	77
PSXRAD message .....	77
Fanbeam MDL message .....	78
Fanbeam MDL message without checksum .....	79
CyScan Kongsberg message .....	79
Detailed interface descriptions .....	80
RS-422 A and B signal definition .....	80
COM 1 and COM 2 .....	80
Connector board .....	81
Ethernet connection .....	81
EU conformity declaration .....	83
<b>EQUIPMENT HANDLING .....</b>	<b>84</b>
Inspection .....	84
Sensor Unit handling .....	84
Safety .....	84
Disposal .....	85
<b>REFERENCES .....</b>	<b>86</b>



# About this manual

## **Purpose of manual**

This installation manual provides you with the necessary information to carry out the mechanical and electrical installation of the SpotTrack system on a vessel.

For information about the operation of this product, refer to the *SpotTrack Operator manual*, see *References* on page 86.

## **Target audience**

This manual is intended for electrical and mechanical workers at a ship yard or system integrator company for installation and configuration of this system.

## **Maintenance purposes**

This installation manual is also intended as reference material for the maintenance personnel. Keep this manual for later use.

# SpotTrack

## System description

SpotTrack is primarily used as a reference system for relative positioning in DP operations. The SpotTrack Sensor Unit is a robust motion stabilised rotating laser sensor which measures range and bearing to one or several reflectors installed on the target platform or vessel. Automatic wave motion stabilisation provides optimum target lock. The onboard Control Unit allows for easy configuration and monitoring of the SpotTrack system.


SpotTrack is a true multi-target sensor with advanced tracking algorithms for true target recognition preventing lock on false reflections.

SpotTrack is capable of reflector tracking in close-by operations by utilising roll and pitch stabilisation. SpotTrack has a wide vertical field of regard which keeps track of targets even at high elevation angles.

The SpotTrack system is easy to install and operate. All moving parts are enclosed within the sensor housing. The mechanical wear due to harsh weather conditions is thus kept at a minimum.

## System diagram

A system diagram for a SpotTrack system replacing an existing Fanbeam system.



### Main units

- 1 SpotTrack sensor with mounting bracket
- 2 Junction box (field)
- 3 Existing Fanbeam power supply
- 4 Junction box (inhouse)
- 5 Control Unit
- 6 Monitor (not included in standard delivery)

### Interfaces and power

- A Power and Ethernet cable (pigtail) between Sensor and Junction box (field), 3 m
- B Fanbeam power cable between Junction box (field) and existing Fanbeam power supply
- C Fanbeam deck cable between Junction box (field) and Junction box (inhouse)
- D Ethernet cable between Junction box (inhouse) and Control Unit
- E Data cable from Control Unit to DP, RS-422
- F VGA cable between Control Unit and monitor

The power cables for the Control Unit and the monitor are not shown.

A monitor is attached to the Control Unit via an SVGA connector. Recommended screen resolution is 1280 x 1024 pixels. Single touch monitors are supported if connected via USB or serial port.

A mouse is the recommended interaction unit, but keyboard support is also fully implemented.

## System units

This system comprises the following main units.


### Sensor Unit

The Sensor Unit is a robust motion stabilised rotating laser sensor which measures range and bearing to one or several retro-reflective targets installed on the target platform or vessel. All moving parts are enclosed within the sensor housing.



### Junction box (field)

The junction box is an interface from the pigtail from the Sensor Unit (carrying both Ethernet and power to the sensor) to the Fanbeam deck cable, power cable.



### Junction box (inhouse)

The junction box is an interface from the Fanbeam deck cable to the Ethernet cable to the Control Unit.




### Control Unit

The Control Unit runs the SpotTrack application software and logs sensor data.

The unit is designed to fit standard 19-inch racks and is typically installed on the bridge or in the instrument room. The unit comprises the following main parts:

- Compact flash card
- Hard disk
- Serial I/O board, Ethernet and computer main board
- Power supply


The power on/off switch, LAN port and USB connection are located under the lid on the left part of the front panel.



The rear panel of the unit contains communication interface ports for interfacing to external sensors. These ports are individually galvanically isolated.

#### Note

*The USB ports are not compatible with USB 3 devices.*



## SpotTrack accessories

### Transportation box

The Sensor Unit is delivered in a specially designed transportation box. Keep the transportation box for later use.



### Protection cover

Protect the Sensor Unit with the protection cover when the system is not in use.



### Cleaning kit

A cleaning agent and cloth are provided in order to clean the Sensor Unit window.



## Scope of supply

### Standard parts provided

- SpotTrack Sensor Unit  
Including 3-metre pigtail cable
- SpotTrack sensor transportation box (please keep this box for later use)
- SpotTrack sensor protection cover (please keep this cover for protection purposes when the system is not in use)
- SpotTrack sensor mounting bracket  
Including mounting kit.
- Control Unit
- Junction box (field)
- Junction box (inhouse)
- Power cable
- Keyboard with trackball
- Single prism (commissioning target)
- Cleaning kit
- End user documentation

## Additional required items

These items are not provided in a standard delivery.

- Monitor
- Ethernet cable
- Data cable
- VGA cable

## Product restrictions

### Restrictions in guarantee

Changes or modifications to the product not explicitly approved by Kongsberg Seatex AS will void the guarantee.

The liability of Kongsberg Seatex AS is limited to repair of this system only under the given terms and conditions stated in the sales documents. Consequential damages such as customer's loss of profit or damage to other systems traceable back to this system's malfunctions, are excluded. The warranty does not cover malfunctions of the system resulting from the following conditions:

- Incorrect power connection.
- The Control Unit and the Sensor Unit housing have been opened by the customer.

## Safety regulations

The laser radiation levels of the SpotTrack sensor have been classified in accordance with IEC 60825-1:2014.

The Sensor Unit is a class 1 laser device under normal operation and reasonably foreseeable single-fault conditions. This means that the sensor is eye safe under all conditions of normal use.

During service, stationary emission can be enabled by the use of specialized software. In this case the sensor is a Class 3R laser device, which is not unconditionally eye-safe.

Location of apertures: Window when cover is on, transmitter lens when cover is off.

Operation of this equipment will not imply any risk for high voltages, explosions or exposure to gas or any chemical and mechanical hazard.

### **WARNING**

---

***The Sensor Unit cover shall not under any circumstances be removed.***

---

*Caution*

---

*Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.*


---

General safety guidelines must be followed when working in mast and on deck.

## Product labels


### Label under the sensor cover

The product information and panel warning label and the hazard triangle are located under the cover, on the base of the unit.



### Labels on the sensor cover

The "Class 1 laser product" label is located on the cover.





## Support information

- **Company name:** Kongsberg Seatex AS
- **Address:** Havnegata 9, 7010 Trondheim, Norway
- **Switchboard:** +47 73 54 55 00
- **Duty phone:** +47 33 03 24 07 (24 hours)
- **E-mail address:** [km.support.seatex@km.kongsberg.com](mailto:km.support.seatex@km.kongsberg.com)
- **Website:** <http://www.kongsberg.com>

# Preparations

## Installation drawings

Installation drawings for the SpotTrack system units are provided in this document.

### Related topics

- *Drawings* on page 60

## Necessary tools and equipment

### Equipment

- RJ-45 plug

### Tools

- RJ-45 plug mounting tool

### SpotTrack Sensor Unit

The Sensor Unit is shipped in a specially designed transportation container. Keep the Sensor Unit within the container until everything is ready for installation of the unit in the mounting bracket. Keep the sensor protection cover in place until the sensor has been mounted.

### Note

---

*After the installation, please save the transportation container. The Sensor Unit must be shipped in this container for service or repair to maintain the warranty.*

---

## Worker skills


Trained electrical workers.

## Location of the system parts

### Sensor Unit

When installing the Sensor Unit, consider the following:

- The Sensor Unit must be mounted in an upright position.
- Place the Sensor Unit on a flat, horizontal surface.
- The Sensor Unit must have free line of sight in the operational zones which the SpotTrack system shall cover.
- Do not place the Sensor Unit in the "beam" of the vessel's radar(s).
- Do not place the Sensor Unit close to the ship's funnel.
- Place the Sensor Unit with the mounting bracket reference point facing directly towards the bow of the vessel. Correct for any deviation in the operating software.



- A** Sensor with vertical mounting bracket
- B** Sensor with horizontal mounting bracket

The arrow on the illustration points towards the bow of the vessel.

### Related topics

- *Sensor Unit reference point* on page 19
- *Setting the mounting bracket parameters* on page 48
- *Installing the Sensor Unit* on page 22
- *Sensor Unit dimensions* on page 61

### Junction box (field)

When installing the junction box, consider the following:

- The junction box can be placed on a wall or a rail.
- Make sure that the location is within the length of the 3-metre sensor cable.
- Provide for a minimum of 100 mm below the connectors.

### Related topics

- *Installing the junction box (field)* on page 24
- *Junction box (field) dimensions* on page 64

## Junction box (inhouse)

- It is recommended to place the junction box close to the Control Unit. It replaces the Fanbeam current loop converter.
- Provide for a minimum of 100 mm below the connectors.

### Related topics

- *Installing the junction box (inhouse)* on page 26
- *Junction box (inhouse) dimensions* on page 65

## Control unit

When installing the Control Unit, note the following:

- The unit is designed for indoor installation. Avoid locations with heavy vibrations, strong electronic fields (close to transformers), excessive heat.
- The unit has an internal fan and requires free airflow from the rear and out to the sides. It is recommended that ventilation or air conditioning is provided in order to keep the ambient operating temperature around +20 °C. The best location is typically in the instrument room or on the bridge mounted on 19-inch rails in a rack or console with good ventilation.
- It is recommended that the area around the unit is kept free from dust and static electricity.
- All connections to the unit are on the rear side and available space for cable connections and service must be provided.

### Related topics

- *Installing the Control Unit* on page 34
- *Control Unit dimensions* on page 66

## Monitor

When installing the monitor, consider the following:

- The unit is designed for installation in an indoor environment and for operation within the temperature range. The best location is typically on a table in the instrument room or on the bridge mounted close to the Control Unit.
- The Control Unit and the monitor should be mounted close to each other to reduce the length of the VGA cable.
- It is recommended that the area around the unit is kept free from dust and static electricity.

### Related topics

- *Installing the monitor* on page 39

## Reflectors

The SpotTrack system is able to track reflectors of different type, strength and location simultaneously. To ensure optimal accuracy and tracking, the following should be considered when mounting the reflectors.

- The reflectors should be placed with a horizontal separation of minimum 5 metres.
- The reflectors which shall be used in the operation should be located with a separation in bearing of minimum 5 degrees.
- The reflectors which shall be used in the operation should be located in approximately the same height if you take into consideration the bearing of the approaching vessels. A separation in elevation less than 50 % of the separation in bearing.
- The reflectors should not be located close to reflective surfaces, such as reflective signs.
- The reflector type and size should be chosen based on expected operating range. A prism, or prism cluster, is recommended for distances larger than 200 metres.


### Related topics

- *Installing the single prism* on page 30
- *Installing the prism cluster* on page 32
- *Prism cluster dimensions* on page 67
- *Single prism holder dimensions* on page 69

## Sensor Unit reference point

The system data regarding range, distance and inclination are measured with reference to a specific point (orientation pin) in the mounting bracket. This is the sensor Origo.

Offsets have to be established between the sensor reference point and the vessel reference point.



**A** Sensor mounting bracket reference point (orientation pin)

### Related topics

- *Setting the mounting bracket parameters* on page 48

## Measuring the mounting bracket orientation

This procedure explains how to measure the mounting bracket orientation relative to the vessel heading.

### Note

---

*This procedure should be performed only when the vessel is at dock.*

---

### Procedure

- 1 Place a test reflector in a known location on the vessel.
- 2 Calculate the correct bearing from the bracket to the test reflector from vessel drawings.
- 3 Adjust the mounting bracket orientation until the measured bearing matches the calculated bearing within 0.1 degrees.

The measured bearing is most accurately observed in the reflector **History view**.

It is of great importance that the mounting bracket orientation is correct. An error in the mounting bracket orientation will give an error in the sensor measurement depending on the distance to the reflector.

The table shows error in position measurement for different combinations of mounting bracket orientation error and distance to reflector.

<b>Error in bracket orientation/Range</b>	<b>50 m</b>	<b>100 m</b>	<b>300 m</b>	<b>500 m</b>	<b>1000 m</b>
0.1 degr	0.09 m	0.17 m	0.52 m	0.87 m	1.75 m
0.5 degr	0.44 m	0.87 m	2.62 m	4.36 m	8.73 m
1.0 degr	0.87 m	1.75 m	5.24 m	8.73 m	17.45 m
3.0 degr	2.62 m	5.23 m	15.70 m	26.17 m	52.34 m

If the vessel position is stationary, the error will not be visible on the DP system even if the heading is changed. If the vessel has a linear velocity relative to the reflector, the error will show up as drift when compared to other reference systems on the DP.

To verify the bracket mounting angle, move the vessel towards or away from the reflector without changing vessel heading. If the SpotTrack sensor is drifting away from the other reference systems, it is likely because of an error in the bracket mounting angle. Note that a drifting gyro can also cause this kind of error.

### Note

---

*If the sensor is removed from the mounting bracket, the bracket mounting angle must be measured again.*

---

### Related topics

- *Setting the mounting bracket parameters* on page 48

- *Checking the reflector history* section in the SpotTrack operator manual, see *References* on page 86.

## Measuring the mounting bracket location

### Procedure

- 1 Calculate the bracket location from the vessel drawings.

The accuracy should be within 1 metre. The bracket location does not affect the accuracy of the sensor measurements.

### Related topics

- *Setting the mounting bracket parameters* on page 48

## Rack requirements

If the product is delivered without a rack, the Control Unit must be installed in a rack which is already in place on site. Consider the following to determine whether your rack is suitable for the Control Unit installation.

- The rack must be securely mounted to the floor.
- The rack must be a standard 19-inch rack.
- The minimum depth of the rack must be 600 mm.
- The rack should have air inlet on top and bottom or ventilation splits on the sides. The Control Unit has ventilation on the sides. Forced ventilation may be required if the rack contains several electronic modules.
- The rack must be mounted in such a way that the minimum cable bends (at the rear side) are not exceeded.
- The rack must be connected to a grounded outlet.

### Related topics

- *Installing the Control Unit in the rack* on page 34


# Installing the Sensor Unit

This chapter describes the Fanbeam replacement installation of the Sensor Unit with the mounting bracket, the junction boxes and the Fanbeam existing power supply.

## Installing the horizontal mounting bracket and the Sensor Unit

The mounting bracket includes all items necessary to install the bracket. The mounting bracket will replace the existing Fanbeam sensor mounting bracket and it will fit on the Fanbeam mount plate.





- A Mounting bracket
- B Insulation plate
- C Insulation sleeve
- D Washer DIN 125 – A 8.4
- E DIN 912 M8x1 x 40 – 28N
- F Spring washer DIN 128 – A8
- G Hexagon nut ISO 4032 – M8 – W – N
- H DIN EN ISO 8741–M6x12–St (orientation pin)

**Procedure**


- 1 Remove the Fanbeam sensor.
- 2 Place the insulation plate on the Fanbeam mount plate.
- 3 Thread the pigtail cable through the bracket.
- 4 Place the Sensor Unit in the bracket.

**Note**

---

*Make sure that the orientation pin in the mounting bracket fits into the opening for the orientation pin at the bottom of the Sensor Unit.*

---



- A Screw M8 x 30, DIN912 (Unbrako)
- B Washer DIN 125 A8,4
- C Opening for cable
- D Orientation pin (elevated)
- E Opening for orientation pin at Sensor Unit bottom

- 5 Fix the sensor to the bracket with three M8 x 30 mm hex head bolts/washers.
- 6 Place the mounting bracket on top of the insulation plate.
- 7 Insert the insulation sleeve.
- 8 Insert the washers and nuts.
- 9 Fasten the nuts firmly.
- 10 Remove the sensor protection cover.

### Related topics

- *Sensor Unit dimensions* on page 61
- *Mounting bracket, horizontal, dimensions* on page 62


## Installing the junction box (field)

The mounting bracket is pre-installed on the junction box. Mounting is possible on 2-inch and 3-inch rails, either horizontally or vertically.

**Note**

*Installation in weather protected areas is generally recommended. When it is required to install junction boxes where they may be exposed to a salt mist atmosphere and thereby risk of corrosion, it is strongly recommended to protect the fastening screws with suitable grease lubricant or copper paste. The screws must be fully covered but avoid any grease or paste on the gasket.*


---



- A** Mast mounting
- B** Rail mounting

**Procedure**

- 1** Find a suitable mounting location for the junction box. The maximum distance from the Sensor Unit is 3 metres.
- 2** Place the U-bolts on the pole or rail and insert the U-bolts in the bracket slots. The slots can accommodate both sizes in both vertical and horizontal directions.



- 3 Insert the washers and fasten firmly with self-locking nuts.

Alternatively the junction box can be mounted to a wall. For wall mounting, remove the mounting bracket and mount the junction box by use of the four mounting holes inside the box.

#### Related topics

- *Junction box (field) dimensions* on page 64

## Installing the junction box (inhouse)


#### Procedure

- 1 Remove the junction box cover by unscrewing the four cover screws.
- 2 Place the junction box onto its mounting position.
- 3 Mark four M6 holes on the mounting surface for the junction box.
- 4 Remove the junction box.
- 5 Drill four M6 holes in the marked positions.
- 6 Check that no metal shavings have entered into the junction box while drilling. If so, remove the metal shavings.
- 7 Replace the junction box onto its mounting position.
- 8 Use screws with washers and self-locking nuts to attach the junction box to the mounting surface.
- 9 Replace the junction box cover and fasten it with the four cover screws.

#### Related topics

- *Junction box (inhouse) dimensions* on page 65

## Cables




- A SpotTrack cable with pigtail connector, 3 m
- B Existing Fanbeam power cable to existing Fanbeam power supply
- C Existing Fanbeam deck cable from junction box (field) to junction box (inhouse)
- D Junction box (inhouse) to Control Unit cable, Ethernet

## Cable from Sensor Unit to junction box (field)

The cable is already connected to the Sensor Unit and must be connected to the junction box (field).

### Sensor Unit to junction box (field) cable wiring

In the junction box, connect the sensor pigtail as illustrated.



Signal	Colour
RXD-	Grey
RXD+	Pink
TXD-	Red/Blue
TXD+	Grey/Pink
0V(-)	Blue
0V(-)	Black
24V(+)	Red
24V(+)	Purple

**Note**

*The ferrite included shall be clamped on the pigtail at the inside of the junction box.*

---

## Cable from junction box (field) to Fanbeam power supply

Use the Fanbeam power cable which is already present on the vessel to connect the junction box to the existing Fanbeam power supply.

## Cable from junction box (field) to junction box (inhouse)

The Fanbeam deck cable already present on the vessel is used to connect the two junction boxes.

### **On the junction box (field)**

Connect the Fanbeam power cable and deck cable to the junction box connectors.

### **On the junction box (inhouse)**

Connect the Fanbeam deck cable to the junction box connector.

## Cable from junction box (inhouse) to Control Unit

Use a shielded patch cable with RJ-45 connectors in both ends to connect from the junction box connector to the LAN 3 port at the back of the Control Unit.

## Connecting the junction box (field) to ground

The junction box must be connected to ground. Connect from the screw available at the back of the junction box to vessel ground.

Note \_\_\_\_\_

*All cable shields shall be connected to ground in the junction box only.*

---



# Installing the single prism

A single prism is included in the delivery for measuring the mounting bracket orientation.


The single prism consists of:

- The prism
- The prism mounting bracket
- A U-bolt kit with screws and washers

## Procedure


- 1 Screw the prism onto the mounting bracket.
- 2 Attach the mounting bracket with the prism to a mast or rail with the provided U-bolts.

## Mast mounting





### Rail mounting



- 3 Remove the protection cap from the prism prior to use.

### Related topics

- *Single prism holder dimensions* on page 69

# Installing the prism cluster

This chapter describes the installation of the prism cluster delivered by Kongsberg Seatex AS. The prism cluster is not a part of the standard delivery.

The SpotTrack prism cluster is delivered in a suitcase consisting of:

- The prism cluster
- The mounting bracket
- An M16 x 35 screw with washers
- A U-bolt kit with screws and washers

## Important


---

Keep the transportation suitcase for storage, transportation or return purposes. Store the prisms with the protection cap on.

---


## Procedure

- 1 Attach the mounting bracket to the prism cluster using the provided M16 x 35 screw.




- 2 Attach the prism cluster with the mounting bracket to a mast or rail with the provided U-bolts.

### Mast mounting



### Rail mounting



- 3 Remove the protection caps from the prisms prior to use.

### Related topics

- *Prism cluster dimensions* on page 67

# Installing the Control Unit

This chapter describes the installation of the Control Unit in a 19-inch rack or cabinet with cabling and interfaces. The system can be delivered with or without a rack.

## Installing the Control Unit in the rack

The unit is a 2U unit designed to fit 19" racks. It is typically installed on the bridge or in the instrument room.

### Context

Context The SpotTrack system can be delivered with or without a rack. If the product is delivered with a rack, the rack units are pre-installed in the rack. If your product is delivered with these units pre-installed, you only have to do the cabling.

A cable strain relief bracket is delivered. The cable strain relief bracket allows for flexibility in the cables without putting stress on the vulnerable points on the cable.

### Important

---

If you have a rack-mountable keyboard in your system, make sure that you have enough space in the rack for the keyboard. A rack-mountable keyboard and mouse will require 1U space in the rack.

### Note

---

*The Control Unit has a plastic film on top, and may have one underneath, to protect from transport scratches. This film must be removed before operation as the plastic film will reduce the heat transfer from the unit and thus cause temperature increase inside the unit.*

---

### Procedure

- 1 Find a suitable place for the unit. Typically on the bridge or in the instrument room.
- 2 Remove any plastic film from the unit.
- 3 Place the unit on rails or shelves in the 19-inch rack. This to ensure that the unit is supported at the rear.

- 4 Fasten the unit with four screws in the front. Minimum 10 cm free space is needed behind the unit for connection of cables.
- 5 Install the AC power cable into the power plug at the rear of the unit and into a suitable grounded power outlet.
- 6 The power supply chassis must be grounded to vessel ground.

## Interfaces

### Front interfaces Control Unit

The power switch, LAN 1 and USB 1 are located behind the lid to the left on the front panel. Push lid on left side to open.

Note \_\_\_\_\_

*The USB port is not compatible with USB 3 devices.*



Connector	Type	Connected to
LAN 1	RJ-45 – 10/100 Mbit/s	Reserved for support
USB	USB	For software upgrade and data logging

### LED indicators Control Unit

At the front of the Control Unit there are four light emitting diodes (LED). The LED to the left indicates power and software status. The other LEDs have for the moment no function and will always be turned off.



### LED indications

- The LED to the left indicates power and software status.

- During start-up the indicator to the left appears red.
- When the software is up and running, the indicator turns green.




## Rear interfaces Control Unit

The rear panel of the unit contains communication interface ports for interfacing to external equipment.

### Note


*The USB ports are not compatible with USB 3 devices.*



Connector	Type	Connected to
LAN 2	RJ-45 – 10/100/1000 Mbit/s	User configurable
USB 2	USB	User configurable
USB 3	USB	User configurable
LAN 3	RJ-45 – 10/100/1000 Mbit/s	Junction Box field ( Junction Box inhouse, Fanbeam)
LAN 4	RJ-45 – 10/100/1000 Mbit/s	User configurable
Mouse	PS/2	Mouse
Keyboard	PS/2	Keyboard
COM 1	9–pin DSub male, RS-232	User configurable
COM 2	9–pin DSub male, RS-232	User configurable
VGA <sup>[1]</sup>	HD15 female	Monitor
COM 9 to COM 14	5–pin terminal, RS-422	User configurable
ALARM	3–pin terminal, relay	Not used in this system
MRU	10–pin terminal, RS-422	Not used in this system
IMU	10–pin terminal	Not used in this system
1PPS	6–pin terminal	Not used in this system
ANALOG OUT	10–pin terminal	Not used in this system
ANALOG IN	6–pin terminal	Not used in this system
100 to 240 V AC	Power	Input of 100 to 240 V AC

1. Note that VGA output connector on Processing Unit provides + 5 V on pin 9 of VGA connector. When KVM switches are used this could cause a problem, if so, use a VGA cable without pin 9 connected.

## Cables



- A** Junction box (inhouse) to Control Unit cable, Ethernet cable  
Use a shielded patch cable with an RJ-45 connector in both ends.
- B** Cable from Control Unit to DP  
Serial cable

### Cable specifications

Type CAT5e STP patch cable or better

## Cable from junction box (inhouse) to Control Unit

### Junction box inhouse end of cable

Connect the patch cable to the RJ-45 connector on the junction box.

### Control Unit end of cable

Connect the patch cable to the LAN 3 port at the back of the Control Unit.


## Cable from Control Unit to DP

### Cable specifications

Type 02 x 2-00.50 mm<sup>2</sup> FRZH (Flame retardant, zero halogen) Shielded 90 °C 250 V

### Serial cable from Control Unit to DP wiring

The serial ports COM 9 to COM 14 are as default configured to RS-422, and any of these can be configured to be an output to the DP.



Pin no.	RS-422 signal
1	RX_A
2	RX_B
3	GND
4	TX_A
5	TX_B



# Installing the monitor

## Installing a standard monitor

A monitor is required to configure and operate the SpotTrack system.

### Context

The display is not part of the standard delivery. You can buy the display from Kongsberg Seatex AS or a local supplier.

### Procedure

- 1 Identify the best mounting location for the display. The screen must be easy to see for the vessel operator.
- 2 Connect the monitor to the connector labelled VGA at the rear panel of the Control Unit.
- 3 Connect the monitor power cable to a power socket.

## Installing a touch screen monitor

A monitor is required to configure and operate the SpotTrack system.

### Context

The display is not part of the standard delivery. You can buy the display from Kongsberg Seatex AS or a local supplier.

The SpotTrack system supports single-click touch screen user interaction when a supported touch screen monitor is connected to the Control Unit.

### Procedure

- 1 Identify the best mounting location for the display. The screen must be easy to see for the vessel operator.
- 2 Connect the display to the connector labelled VGA at the rear panel of the Processing Unit.
- 3 Connect the monitor power cable to a power socket.

## Result

You have now connected the monitor to the Control Unit and afterwards you must connect the USB cable or serial cable which communicates the touch commands to the Control Unit and enable allocation of serial port.

These touch screen monitors are supported:

- Winmate Communication (Marine Bridge Systems Display)
- ISIC (Duramon)
- Hatteland Display (Series 1 Maritime Multi Display (MMD))

## Winmate Communication monitor

The Winmate Communication monitor uses a USB cable to communicate touch commands to the Control Unit.

## Procedure

- 1 Connect the USB cable from the touch screen monitor to a USB port at the rear panel of the Control Unit.

## ISIC and Hatteland Display monitors

The ISIC and Hatteland Display monitors use a serial cable to communicate touch commands to the Control Unit.

For these monitors a Windows service has to be enabled to allocate serial port COM1 on the Control Unit as the serial line is used to communicate touch commands from the monitor.

## Procedure

- 1 Connect the serial cable from the touch screen monitor to the COM 1 port at the rear panel of the Control Unit.
- 2 After powering up the system, open the **Windows Task Manager** with the **Ctrl+Alt+Del** keys.
- 3 Select the **File** menu → **New Task**.
- 4 Type `services.msc` and press **Enter**.
- 5 In the service list, locate the **MT7 Serial Search Service**.
- 6 Right-click the service and select **Properties**.
- 7 Change the **Startup type** from Disabled to **Automatic**.
- 8 Select **OK** and close the service list dialog box.
- 9 Reboot the Control Unit from the **System** menu → **Tools** → **Reboot**.

# Interfacing to MRU

The SpotTrack sensor is capable of using data from a Motion Reference Unit (MRU) for improved motion compensation and target tracking in heavy sea conditions. The variables roll, pitch, yaw and heave are all used to improve performance if they are available from the MRU.

The MRU configuration is done using the MRC+ application and a laptop, see the *MRU Installation Manual* in *References* on page 86 for details.

## 4<sup>th</sup> generation MRU settings

A 4<sup>th</sup> generation MRU is recognized by its blue colour and serial number below 20000. The MRU must be connected to the **MRU** serial port on the Control Unit.

### General settings

These general settings are compatible with default settings on the Control Unit.

- Serial interface with baud rate **57600** and signal **RS-422**.
- Interval **20 ms**.

### Specific settings for MRU H, MRU 4, MRU 5, MRU 5+ and MRU 6

- Output **MRU normal** with token **35** and variables **63(Roll)**, **64(Pitch)**, **105(PosMonD)**, **65(Yaw)** as float.  
(Requires MRU software version 3.55 or newer).
- Output **MRU normal** with token **35** and variables **63(Roll)**, **64(Pitch)**, **105(PosMonD)** as float.  
(If the MRU software version is older than 3.55).
- Monitoring point = sensor mounting bracket reference point.
- Heave filter type **Hydrographic survey**.
- See the *MRU Installation Manual* for configuration of heave filter **period** and **damping**.


### Specific settings for MRU Z (MP arm <10 m), MRU 3 (MP arm <20 m)

- Output **MRU normal** with token **35** and variables **63(Roll)**, **64(Pitch)**, **105(PosMonD)** as float.

- Monitoring point = sensor mounting bracket reference point.
- Heave filter type **Hydrographic survey**.
- See the *MRU Installation Manual* for configuration of heave filter **period** and **damping**.

### Specific settings for MRU D, MRU Z (MP arm >10 m), MRU 2, MRU 3 (MP arm >20 m)

- Output **MRU normal** with token **35** and variables **63(Roll)**, **64(Pitch)** as float.



1 MRU sensor unit

A Cable from MRU sensor unit to MRU port on Control Unit

### Related topics

- *Sensor Unit reference point* on page 19

## 5<sup>th</sup> generation MRU settings

A 5<sup>th</sup> generation MRU is recognized by its gray colour and serial number above 20000. The MRU must be connected to the SpotTrack network (CU and sensor) via a dedicated switch. This switch is not delivered by Kongsberg Seatex AS. Alternatively, the MRU can be connected directly to the Control Unit via Ethernet or the **MRU** serial port.

### General settings, MRU connected to Ethernet port on Control Unit

If the MRU is connected to an Ethernet port on the Control Unit, the following general settings are compatible with default settings on the sensor and the Control Unit.

- Reconfigure MRU IP address from default to:
  - **192.168.2.210** if connected via a switch to LAN 3

- **192.168.3.210** if connected directly to LAN 4
- Ethernet interface, UDP broadcast to remote port **7551**.
- Interval **20 ms**.

### **General settings, MRU connected to MRU serial port on Control Unit**

If the MRU is connected to the MRU serial port on the Control Unit, the following general settings are compatible with default settings on the Control Unit.

- Serial interface **COM 1** with baud rate **57600** and signal **RS-422**.
- Interval **20 ms**.

### **Specific settings for MRU E, MRU H, MRU 3 (MP arm <20 m), MRU 5, MRU 5+**

- Output **MRU normal** with token **35** and variables **63(Roll)**, **64(Pitch)**, **326(PosMp1\_D)**, **65(Yaw)** as float.  
(Requires MRU software version 5.02.01 or newer).
- Output **MRU normal** with token **35** and variables **63(Roll)**, **64(Pitch)**, **326(PosMp1\_D)** as float.  
(If the MRU software version is older than 5.02.01).
- Location **Monitoring Point 1**.
- Monitoring point = sensor mounting bracket reference point.
- Heave filter type **Hydrographic survey**.
- See the *MRU Installation Manual* for configuration of heave filter **period** and **damping**.

### **Specific settings for MRU 3 (MP arm >20 m)**

- Output **MRU normal** with token **36** and variables **63(Roll)**, **64(Pitch)**, **65(Yaw)** as float.  
(Requires MRU software version 5.02.01 or newer).
- Output **MRU normal** with token **35** and variables **63(Roll)**, **64(Pitch)** as float.  
(If the MRU software version is older than 5.02.01).

### **Specific settings for MRU D, MRU 2**

- Output **MRU normal** with token **35** and variables **63(Roll)**, **64(Pitch)** as float.


#### **Note**

---

*If heave is used and the SpotTrack sensor is to be used in several mounting brackets on the vessel, the MRU has to be reconfigured with correct monitoring point when the sensor is moved to a new bracket. Alternatively, different UDP output channels with different monitoring points and remote UDP ports may be defined for each of these brackets. Then, if the sensor is moved to another bracket, the SpotTrack sensor can be configured to read the correct UDP port.*

---

Recommended version with net switch is illustrated.



- 1 MRU sensor unit
- 2 Net switch
- A Cable from net switch to MRU sensor unit


**Related topics**

- *Sensor Unit reference point* on page 19

# Cable layout and interconnections

## Cable plan

Cable plan for the SpotTrack system replacing existing Fanbeam system.



### Related topics

- *SpotTrack system drawing on page 71*

## List of cables

List for cables for the SpotTrack system with Fanbeam replacement.

**A — SpotTrack Sensor Unit to junction box (field)**

This is a 3-metre power and Ethernet cable. The cable is attached to the Sensor Unit.

**B — Junction box (field) to existing Fanbeam power supply**

This is a power cable. The Fanbeam power cable is already present on the vessel.

**C — Junction box (field) to junction box (inhouse Fanbeam type)**

This is the Fanbeam deck cable already present on the vessel. This cable is not delivered by Kongsberg Seatex AS.

**D — Junction box (inhouse) to Control Unit**

This is an Ethernet cable. Any standard shielded patch cable with suitable length can be used. This cable is not delivered by Kongsberg Seatex AS.

**E — Control Unit to DP**

This is a serial cable. Type 02 x 2-00.50 mm<sup>2</sup> FRZH (Flame retardant, zero halogen) Shielded 90 °C 250 V. This cable is not delivered by Kongsberg Seatex AS.



**F — Control Unit to monitor**

This is a standard VGA cable. This cable is not delivered by Kongsberg Seatex AS.



# Configuration

This chapter describes the parameters which have to be set before the SpotTrack system can be put to use.

Select the **System menu** button, , in the top right corner of the **Main** view to open the **System** menu. When the **System** menu is displayed, this button changes to a **Close** button, . Select the **Close** button to close the **System** menu.

## Selecting configuration parameters

There are three ways to select a configuration parameter:

- Selecting a button directly
- Selecting from a drop-down menu
- Editing in text boxes


## Displaying the keypad

If you do not use a mouse and keyboard you can select to display a keypad on the screen for entering values.

- 1 Select the **System** menu → **Settings** → **Display**
- 2 Select **Display keypad** ON or OFF.



## Editing in text boxes

Select the **Pencil**  next to the box to modify the value. Select **OK** when the correct information is entered.



## Setting the mounting bracket parameters


All point locations in the configuration refer to the survey origin. The location of the origin is defined using distance from stern, center line and keel (often referred to as the CRP).

### Note

*The coordinate reference point (CRP) is defined to be in the intersection between stern, longships centre line and keel. In case the keel is not parallel with the base line, the reference for CRP is where the keel crosses the vertical section amidships.*

The mounting bracket orientation relative to the vessel heading has to be defined.

The mounting bracket location is entered relative to a survey reference point (Origin). The origin is defined relative to CRP (Coordinate Reference Point). The location along the X axis (centre line) is positive towards the bow. The location along the Y axis is positive towards starboard, and the location along the Z axis is positive downwards.



### Procedure

- 1 Select the **System menu** button in the upper right corner of the **Main** view.
- 2 Select **Settings** → **Bracket**.
- 3 Locate the **Survey origin** text boxes. Type the survey origin coordinates.  
In case a survey report is not available, the coordinates can all be 0.00.

Bracket location

Survey origin

X (forward) [m]      Y (starboard) [m]      Z (down) [m]

0.00    0.00    0.00

Bracket location (from survey origin)

X (forward) [m]      Y (starboard) [m]      Z (down) [m]      Orientation [°]

20.00    0.00    -15.00    0.6

Bracket location (from center of gravity)

Z (down) [m]

-11.00

- 4 Locate the **Bracket location** text boxes. Type the mounting bracket orientation in degrees (-180 to 180) relative to the vessel heading in the **Orientation** text box.  
For example, when the mounting bracket orientation is directly starboard, type 90.
- 5 Type the bracket location values into the corresponding text boxes.
- 6 Type the vertical bracket location from the centre of gravity into the text box.
- 7 Close **Settings** when finished.

### Related topics

- *Measuring the mounting bracket orientation on page 20*
- *Measuring the mounting bracket location on page 21*

## Setting the blind zone

Walls or other large items on the vessel may cause reflections that are of no interest to the SpotTrack operator. In this case, a blind zone shall be defined for the sensor.

The Sensor Unit blind zone is measure relative to the Sensor Unit/bracket.

Sensor blind zone and search area

Blind zone

Direction

180

Sector angle

20

Default sensor search area

Elevation angle top

12

Elevation angle bottom

-5

### Procedure

- 1 Select the **System menu** button in the upper right corner of the **Main** view.
- 2 Select **Settings** → **Sensors**.
- 3 Type the wanted **Direction** and **Sector angle** for the blind zone.


#### *Example 1 Blind zone*

A 20-degree blind zone appears behind the sensor. Then enter 180 as **Direction** and 20 as **Sector angle**.

- 4 Close **Settings** when finished.

## Setting the sensor search area

The sensor's vertical search sector has to be defined. No reflector will be found or tracked outside this area. The values configured here are the values used when resetting the search area to default during operation.



### Procedure

- 1 Select the **System menu** button in the upper right corner of the **Main** view.
- 2 Select **Settings** → **Sensors**.
- 3 Type the wanted **Elevation angel top** and the **Elevation angle bottom**.
- 4 Close **Settings** when finished.

### Related topics

- See section on *Changing the sensor search area* in the *SpotTrack operator manual, References* on page 86.

## Setting up the DP interface

The **DP interface settings** controls output from the SpotTrack system to a DP.

### Context

#### Note



*The default serial communication parameters are 9600 baud, no parity, 8 data bits and 1 stop bit. This can be modified in the **Advanced Configuration SpotCore** application. Please contact Customer Support for directions on how to change these parameters if needed.*

#### Note

*The Fanbeam MDL message without checksum has to be chosen through the **Advanced Configuration SpotCore** application. Select **Root** → **Communications** → **DataIf** → **TelegramOutput** → **TelegramOut1**. Set the value of the **Output** field to 7. To make it clear which telegram is selected, write **Fanbeam MDL message without checksum** in the **Description** field.*

### Procedure

- 1 Select the **System menu** button in the upper right corner of the **Main** view.
- 2 Select **Settings** → **DP**.
- 3 Select the desired telegram output by selecting the corresponding button under **Telegram to DP**.
- 4 Set the maximum number of reflectors in the **Max DP targets** text box.
- 5 Select the desired communication type (IP or Serial) by selecting the corresponding button under **Communication type**.
- 6 If **Serial** is selected, select the desired COM port from the drop-down list. The displayed port names correspond to the labels at the rear of the Control Unit.
- 7 If **IP** is selected, enter the desired IP address. Then select the designated **IP port** in the range 1024 to 65535.




- 8 The **Cable ID** box is optional, intended for installation documentation.
- 9 Close **Settings** when finished.

## Setting up the MRU

The MRU port has to be defined if an MRU sensor unit is connected. The **Status ON/OFF** button either enables or disables reading of MRU data.

### Procedure

- 1 Select the **System menu** button in the upper right corner of the **Main** view.
- 2 Select **Settings** → **MRU**.
- 3 Select the wanted communication type, **IP** or **Serial**.
- 4 If **IP** is selected, type the MRU port used for the current SpotTrack sensor location.
- 5 If **Serial** is selected, select serial port from the drop-down list.
- 6 Close **Settings** when finished.



The **Cable ID** box is optional, intended for installation documentation.


## Setting up the display

The orientation of the vessel in the **Radar** view can be changed in steps of 90 degrees by selecting the **Left** or **Right** arrows.

The measurement types which can be selected are **RNG/BRG** (range and bearing) or **X/Y** (cartesian coordinates relative to vessel heading). When measurement type **X/Y** (cartesian coordinates) is selected, the absolute value is displayed. Sign is indicated with **AFT/FWD** or **PRT/STB**.

The measurement units which can be selected are **m** (metres) or **ft** (feet).

If you use a touch screen, setting **Display keypad** to **ON** will enable an on-screen keypad for number entry.



### Selecting Radar view orientation

You can select the orientation of the **Radar** view to 4 different orientations. This can be done to fit how the display is installed on the vessel.

### Procedure

- 1 Select **System menu**, **+**, → **Settings** → **Display**
- 2 Select the **Right** or **Left** arrow to change the vessel orientation in steps of 90 degrees.



## Selecting measurement type

The SpotTrack system supports presentation of the distance to reflectors in both polar and cartesian coordinates.

### Context


The **Transponder list** reflects how the measurement types are presented.

### Note

*The **Radar** view is not affected by this setting.*

Figure 1 Measurement type RNG/BNG

Figure 2 Measurement type X/Y



### Procedure


- 1 Select the **System menu** button in the upper right corner of the **Main** view.
- 2 Select **Settings** → **Display**.
- 3 Select **RNG/BRG** to select range and bearing as measurement type or select **X/Y** to select cartesian coordinates relative to vessel heading as measurement type.



## Selecting measurement unit

You can select which measurement unit you want to use in the display.

### Procedure

- 1 Select **System menu**, , → **Settings** → **Display**


- 2 Select **m** to select metres as measurement unit or select **ft** to select feet as measurement unit.



## Setting the parameters for network communication

### Setting the SpotTrack sensor IP address

The Sensor Unit IP address must be set manually for the Sensor Unit to communicate with the Control Unit.



### Procedure

- 1 Select the **System menu** button in the upper right corner of the **Main** view.
- 2 Select **Tools** → **Network discovery**.
- 3 Select **Poll** and the sensor should show up in the list.
- 4 Select **Change IP** to the sensor IP address.

The default sensor IP address is **192.168.2.200**. When the sensor is installed, change this address to **192.168.2.201**. This is to avoid IP address conflicts if another sensor is connected to the network.



## Connecting the Control Unit to the SpotTrack sensor

The Control unit IP address (LAN 3) is read-only and shows the IP address of the network interface through which data are received on the Control Unit.

SpotTrack system IP settings

LAN4  
0 . 0 . 0 . 0

LAN1  
0 . 0 . 0 . 0

LAN2  
0 . 0 . 0 . 0

LAN3  
192 . 168 . 2 . 50

SpotTrack sensor IP address  
192 . 168 . 2 . 200

SpotTrack sensor cable ID  
Not defined

The **SpotTrack system IP address** to which the Control Unit connects, can be changed if required. In the figure, a manually selected address is indicated. The LED in the **Active** button on the **System** menu will light up when successfully connected to the SpotTrack sensor. The default sensor IP address is: **192.168.2.200**.



The **SpotTrack sensor cable ID** box is optional, intended for installation documentation.

### Procedure

- 1 Select the **System menu** button in the upper right corner of the **Main** view.
- 2 Select **Settings** → **Network**.
- 3 For LAN 3, type the SpotTrack sensor IP address.
- 4 The **Cable ID** box is optional, intended for installation documentation.
- 5 Close **Settings** when finished.

## Setting up the Control Unit for remote connection

The LAN 4 network port on the Control Unit is used for K-IMS communication for remote maintenance and support with a direct connection to a K-IMS router. The default IP address is: 172.20.35.50.

### Procedure

- 1 Select the **System menu** button in the upper right corner of the **Main** view.
- 2 Select **Settings** → **Network**.
- 3 For LAN 4, type the K-IMS router IP address.
- 4 Close **Settings** when finished.

SpotTrack system IP settings

LAN4  
0 . 0 . 0 . 0

LAN1  
0 . 0 . 0 . 0

LAN2  
0 . 0 . 0 . 0

LAN3  
192 . 168 . 2 . 50

SpotTrack sensor IP address  
192 . 168 . 2 . 200

SpotTrack sensor cable ID  
Not defined

## Setting vessel shape and vessel dimensions

Under **Vessel** you can enter a vessel name, a vessel MMSI and vessel dimensions for a correct scaling of the vessel image in the **Radar** view.

### Entering vessel name and MMSI

#### Procedure

- 1 Select the **System menu** button in the upper right corner of the **Main** view.
- 2 Select **Settings** → **Vessel**.
- 3 Select the **Pencil** to modify the value.
- 4 Type the vessel name and a vessel MMSI.
- 5 Select **OK** to confirm.

Vessel shape and dimensions

Name: Vessel

MMSI: 257123456

Dimensions [m]

Length: 100.00

Width: 20.00

Height: 20.00

## Entering vessel dimensions

### Procedure

- 1 Select the **System menu** button in the upper right corner of the **Main** view.
- 2 Select the **Settings** → **Vessel**.
- 3 Select the **Pencil** to modify the value.
- 4 Type the value for **Length**, **Width** and **Height**.
- 5 Select **OK** to confirm.


## Verifying data communication

**Tools** holds the diagnostic tools. Under **Diagnostics** you will find the **Port Monitor** tool. This is an advanced tool used to diagnose how data are transported in the SpotTrack system.

## Displaying sensor raw data

### Procedure

- 1 Select the **System menu** button in the upper right corner of the **Main** view.
- 2 Select **Tools** → **Diagnostics** → **Port Monitor**.
- 3 Serial interfaces are displayed in the **Serial** tab and IP interfaces in the **UDP** tab.
- 4 Select the desired interface, then observe that received and sent information through that interface is displayed in the lower windows.
- 5 To avoid displaying non-ASCII characters, select **Text mode**. **Binary mode** is the default.
- 6 Select **Freeze** to stop updating the data. Then, select **Unfreeze** to continue updates.



## Checking the system functionality

A functional test can verify if the system works as intended.

### Procedure

- 1 Place a test reflector in a known location on the vessel

- 2 Calculate the correct range and bearing from the mounting bracket to the test reflector from vessel drawings
- 3 Read the measured range and bearing to the test reflector from the SpotTrack **Reflector list**.
- 4 Check the measured values against the calculated values.

## Checking the sensor serial number, product and software version

Select **About** under **Settings** to see the SpotTrack serial number, the product version and the software version installed on the system.

## Replacing or moving the sensor

Note

---

*If the sensor is replaced with a new one, or moved to another location on the vessel, it has to be re-configured.*

---

These settings have to be re-configured if the sensor is replaced or moved:

- The mounting bracket orientation.
- The blind zone.
- The mounting bracket location.
- The MRU UDP if an MRU sensor is connected.

Note

---

*If the sensor is replaced, a full software upgrade from a USB stick is recommended to ensure that the software versions on the SpotTrack sensor and the Control Unit are compatible*

---

### Related topics

- *Setting the mounting bracket parameters* on page 48
- *Setting the blind zone* on page 49
- *Setting up the MRU* on page 52


## Automatic logging

The SpotTrack Control Unit will automatically log data that may serve as documentation or help to diagnose the cause of possible problems.

There are 6 categories of log files. All of these have a **History** variable, defining the maximum age of the log files created.

Each file has a length of **MaxTime** minutes.

The default logging interval is 21 days.



## Changing the log length

### Procedure

- 1 Select the **System menu** button in the upper right corner of the **Main** view.
- 2 Select the **Tools** → **Advanced Configuration SpotCore**.
- 3 Locate **Root** → **Logging** and select the wanted log category.
- 4 Modify the **History** and **MaxTime** values.
- 5 When finished, select **Apply** and confirm changes before closing the application.

# Drawings

This chapter contains outline drawings showing mechanical dimensions of the Sensor Unit, the mounting bracket, the junction box and the Control Unit.


**Note**

---



*The drawings are not to scale. To-scale drawings are available on request.*

---

# Sensor Unit dimensions



Tolerance : ISO 2768-M if not specified on drawing

 <b>Kongsberg Seatex AS</b> Project / Product name : <b>3155/Spottrack</b>		Title : <b>Instrument complete Spottrack</b> Drawing type : <b>Mechanical</b>		Sheet : <b>2 of 9</b> Size : <b>A3</b> Scale : <b>1:3</b>
Projection : 		Issued : <b>04.11.2014</b> Document ID : <b>3155-MA-001</b>		Supp : <b>KoHa</b> Revision : <b>01</b>
<small>The reproduction, distribution and utilization of this document as well as the communication of its contents to others without authorization is prohibited. Offenders will be held liable for the payment of damages, as follows: in the event of a patent, utility model or design.</small>				

# Mounting bracket, horizontal, dimensions

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	3155-MD-149		1
2	3155-MD-151	Insulation Plate	1
3	Insulation sleeve		4
4	Washer DIN 125 - A 8.4		4
5	DIN 912 M8x1 x 40 --- 28N		4
6	Spring washer DIN 128 - A8		4
7	Hexagon Nut ISO 4032 - M8 - W - N		4
8	DIN EN ISO 8741-M6x12-St		1


  
  

Rev.	Changes	Date	Sign.
00	First issue	03.09.2014	RoHa
01	Added sheet	05.09.2014	RoHa

Tolerance: ISO2768-M if not specified on drawing

	<b>Kongsberg Seatex AS</b>	Title: <b>Horizontal bracket</b>	Sheet: <b>1 of 2</b>
Project / Product name: <b>3155/Spottrack</b>	Projection:	Drawing type: <b>Mechanical</b>	Size: <b>A3</b>
The reproduction, distribution and utilization of this document as well as the communication of its contents to others without authorization is prohibited. Offenders will be held liable for the payment of damages. An objection to the copyright is not a ground for liability, unless it is proven.	Document ID: <b>3155-MA-007</b>	Issued: 05.09.2014	Scale: <b>1:2</b>
		RoHa	Revision: <b>01</b>





Tolerance: ISO2768-M if not specified on drawing

 <b>KONGSBERG</b> Project / Product name: <b>3153/Spottrack</b>	Title: <b>Horizontal bracket</b>	Sheet: <b>2 of 2</b>
	Drawing type: <b>Mechanical</b>	Size: <b>A3</b>
Projection: 	Issued: <b>05.09.2014</b>	Scale: <b>1:2</b>
The reproduction, distribution and utilization of this document as well as the communication of its contents to others without authorization is prohibited. Offenders will be held liable for the payment of damages. An objection received in the event of print or printing errors or design	Document ID: <b>3155-MA-007</b>	RoHa Revision: <b>01</b>

# Junction box (field) dimensions

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	3155-MD-156		1
2	ROLEC_110_162_000_b_028	Box, Rolec	1
3	110_162_000_c	Lid, Rolec	1
4	HSK_K_Ext_1_291_2001_50_black_	Cable gland_M20x1.5	1
5	Ampheno_PT07A-10-2P003		1
6	Ampheno_PT07A-12-8S003		1

Rev.	Changes	Date	Sign.
00	First issue		

Tolerance: ISO2768-M if not specified on drawing

**Kongsberg Seatex AS**  
 Title: Junction Box Field Fanbeam  
 Drawing type: Mechanical  
 Document ID: 01.10.2014  
 Revision: 00

MW SYSTEMS  
 Project / Product name: 3155/Spottrack  
 Projection: Mechanical  
 Date: 01.10.2014  
 RoHa  
 Revision: 00

This reproduction, distribution and utilization of this document as well as the communication of its contents to others without authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of patent, utility model or design.

# Junction box (inhouse) dimensions

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	ROLEC_110_162_000_b_029	Box, Rolec	1
2	110_162_000_c	Lid, Rolec	1
3	HSK_K_EX_T_291_2001_50_black	Cable gland_M20x1.5	1
4	Amphenol_PT07A-12-9P003	Amphenol connector	1

4 x fixing holes,  
max. Bolt: M6

Rev.	Changes	Date	Sign.
00	First issue		

**Tolerance: ISO2768-M if not specified on drawing**


**MUSKATLIG**  
Kongsberg Seatex AS  
Project/Package Name: 3155/Spottrack

**Projection:** Mechanical  
Document ID: 01.10.2014  
RoHa REVISION: 01


Title: Junction Box  
Internal Fanbeam  
Drawing type: Mechanical  
Issued: 01.10.2014  
RoHa REVISION: 01


The reproduction, distribution and utilization of this document as well as the communication of its contents to others without authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of patent, utility model or design.

# Control Unit dimensions



# Prism cluster dimensions







Mast installation

Tolerance: ISO2768-M if not specified on drawing		Sheet 2 of 2	
Project / Product name <b>KONGSBERG</b> 3155/Spottrack		Title Prism cluster Spottrack	
Projection: 1st angle		Drawing type Mechanical	
This drawing is the property of Kongsberg Seatex AS. It is not to be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without prior written permission from Kongsberg Seatex AS. All rights reserved in the event of patent, utility model or design.		Issue date 07.10.2014	
		Revision 00	


# Single prism holder dimensions



Rev.	Changes	Date	Sign.
00	First issue		
Tolerance: ISO2768-M if not specified on drawing			
<b>Kongsberg Seatex AS</b>			
Project / Product name: <b>3155/Spottrack</b>			
Drawing type: <b>Mechanical</b>			
Assesst: <b>07.10.2014</b>			
Title: <b>Single prism Holder</b>			
Sheet: <b>2</b>			
Size: <b>A3</b>			
Scale: <b>1:2</b>			
Author: <b>RoHa</b>			
Part no.: <b>3155-MA-034</b>			
Revision: <b>00</b>			



*Mast installation*




*Rail installation*

Tolerance: ISO2768-M if not specified on drawing		Sheet 2 of 2	
Project / Product name <b>Kongsberg Seatex AS</b>		Title <b>Single prism Holder</b>	
Project / Product name <b>3155/Spottrack</b>		Drawing type <b>Mechanical</b>	
Projection: 1st angle		Issue: <b>07.10.2014</b>	
This drawing is the property of Kongsberg Seatex AS. It is not to be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without the prior written permission of Kongsberg Seatex AS. All rights reserved in the event of patent, utility model or design.		Revision <b>00</b>	
		Part No. <b>3155-MA-034</b>	



# SpotTrack system drawing



- \*NOTE: 1.5m cable delivered by Kongsberg
- \*\*NOTE: Optional equipment.
- \*\*\*NOTE: Not delivered by Kongsberg
- \*\*\*\*NOTE: Existing equipment.

Rev.	A	28.01.2015	First Issue	Description	THR	BH	ILB
Date					Designed by	Checked by	Approved by
				SpotTrack Fanbeam Replacement Kit			
				System Drawing			
				Cable Layout			
				Project / Product name			
				Kongsberg Maritime AS			
				SEATEX			
				Trondheim			
				Project number			
				3155			
				Drawing type			
				Cable Layout			
				Sheet			
				1			
				Size			
				A3			
				Scale			
				A			
				Revision			
				A			

# Technical specifications

## Performance specifications

Laser classification	Eye Safe Class 1 IEC 60825
Laser wavelength	905 nm
DP range prism reflector	10 to 1500 m <sup>[2]</sup>
DP range tape reflector	10 to 350 m <sup>[3]</sup>
Horizontal pos. accuracy (2 $\sigma$ )	1 m @ 1000 m range
Bearing accuracy (2 $\sigma$ )	1 mrad
Vertical angular accuracy (2 $\sigma$ )	0.2°
Vertical angular coverage forward	-40° to 60°
Vertical angular coverage aft	-26° to 54°
Horizontal angular coverage	360°
Scanning frequency	1 Hz

## Weights and outline dimensions

### Sensor Unit

Type	Spot-E-Sensor_01
Circumference	Ø 173 with bracket
Height	472 mm
Weight	6 kg

- 
2. Depending on reflector type, size and atmospheric conditions.
  3. Depending on reflector type, size and atmospheric conditions.

## Control Unit

Height	88.1 mm (2U)
Width	485 mm (19")
Depth	Min 357 mm (including connectors on rear panel) and max 412 mm (including cable relief bracket)
Weight	5.4 kg

## Junction box (field)

Type	Spot-E-JBF-Fan
Length	268 mm
Width including connectors	192 mm
Height without bracket	99 mm
Height with bracket	160 mm
Weight	3.95 kg including bracket

## Junction box (inhouse)

Type	Spot-E-JBI-Fan
Length	268 mm
Width including connectors	192 mm
Height	99 mm
Weight	2.7 kg

## Power specifications

### Sensor Unit

Type	Spot-E-Sensor_01
Input voltage	24 V DC +/- 1 V, supplied by the junction box
Power consumption	Max. 30 W

## Control Unit

Voltage	100 – 240 V AC, 50/60 Hz
Power consumption	Max. 60 W
Batteries	None, connection to uninterruptible power supply (UPS) recommended

## Junction box (field)

Type	Spot-E-JBF-Fan
Voltage	12 to 35 V DC
Power consumption	Max. 6 W

## Junction box (inhouse)

Type	Spot-E-JBI-Fan
Voltage	12 to 35 V DC
Power consumption	Max. 3 W

# Environmental specifications

## Sensor Unit

Operating temperature range	-25 °C to +55 °C
Storage temperature range	-40 °C to +70 °C
Operating humidity	100 %
Storage humidity	90 %
Enclosure material	Anodised aluminium and hard coated acrylic
Enclosure protection	IP 66
EMC compliance	IEC 60945/EN 60945

## Control Unit

Enclosure material	Aluminium
Operating temperature range	-15 °C to +55 °C <sup>[4]</sup>
Recommended operating temperature	Room temperature (+20 °C)

---

4. Operating temperature up to +55 °C for 10 hours.

Storage temperature range	-20 °C to +70 °C <sup>[5]</sup>
Operating humidity	Max. 95 % non-condensing
Storage humidity	Less than 55 %
Ingress protection front	IP 42
Ingress protection rear	IP 21
Electromagnetic compatibility (immunity/emission)	IEC 60945/EN 60945
Vibration	IEC 60945/EN 60945

## Junction box

Type	Spot-E-JBF_01, Spot-E-JBF-Fan, Spot-E-JBI-Fan
Enclosure material	Aluminium
Operating temperature range	-25 °C to +70 °C
Storage temperature	-25 °C to +70 °C
Ingress protection	IP 66

## Cable specifications

Recommended cables.

### Power and Ethernet cable

Type	Lapp, Unitronic, FDCCP, 6 x 2 x 0.25 mm <sup>2</sup>
Connectors	Pigtail and Molex 12-pin

### Ethernet cable

Type	Draka ToughCat7_S_FTP or similar
------	----------------------------------

### Power cable

Type	Draka TI (I) 250V, Shipline, 1 Quad 0.5 mm <sup>2</sup> , halogen free or similar cable for exposed maritime use
------	--

### Serial cable

Type	02 x 2 – 00.50 mm <sup>2</sup> , FRZH (Flame retardent, zero halogen), shielded, 90 °C, 250 V
------	---

---

5. Recommended long term storage temperature range between +5 to +35 °C.

### VGA cable

Type	Standard VGA cable
------	--------------------

## External interfaces

### Sensor Unit

Serial ports	1 RS-422
Ethernet/LAN	1

### Control Unit

Serial ports	6 non-dedicated isolated ports, RS-232 or RS-422 <sup>[6]</sup> Isolated COM1 and COM2, 9-pin DSub, RS-232
Baud rate	Up to 115 200 bytes/sec
LAN	4 Ethernet ports
USB	3 ports, 1 in front and 2 in rear

## Product safety specifications

### Sensor Unit

Electrical safety compliance	IEC 61010-1/EN 61010-1
Eye safety compliance	IEC 60825

### Control Unit

Electrical safety (LVD) <sup>[7]</sup>	IEC 61010-1/EN 61010-1
--	------------------------

## Compass safe distance

Observe the physical distance to the compass if you place the Control Unit on the bridge as a stand-alone unit. These measurements apply to the unit mounted in a 6U rack.

---

6. Number of serial ports may be expanded by using a serial port extender.

7. This equipment is intended for professional use only.

- |                  |  |
|------------------|--|
| Standard compass | <ul style="list-style-type: none"> <li>• 200 cm – non-energized</li> <li>• 280 cm – non-energized after magnetisation</li> <li>• 200 cm – energized and operating</li> </ul> |
| Other compass    | <ul style="list-style-type: none"> <li>• 130 cm – non-energized</li> <li>• 190 cm – non-energized after magnetisation</li> <li>• 130 cm – energized and operating</li> </ul> |

**Note**

---

*If the unit is placed in a larger rack, please observe the compass safe data for that specific rack. If no such data are available, the compass safe distance is 5 metres.*

---

## Telegram types

### SpotTrack message

**Format**

\$PSXST, n, rrrr.rr, a.a, bbb.bb, s.ss, SS\*cc

- 1 n = Reflector DP ID
- 2 rrrr.rr = Horizontal distance in meters, decimal centimeters
- 3 a.a = Distance accuracy estimate. Set fixed to 0.1
- 4 bbb.bb = Bearing to reflector 000.00 to 359.99 degrees
- 5 s.ss = Bearing accuracy estimate. Set fixed to 0.05
- 6 SS = 09 – Valid Status
- 7 \*cc = Computed checksum
- 8 <cr> = Carriage return
- 9 <lf> = Line feed

*Example 2 SpotTrack message*

\$PSXST,1,0156.89,0.1,028.23,0.05,09\*62

\$PSXST,2,0906.41,0.1,079.25,0.05,09\*64

### PSXRAD message

**Format**

\$PSXRAD, I, hhmmss.ss, nn, ss, id, rrrr.rr, aa.a, bbb.bb, ss.ss, ±vv.vv,

ff.f,±dd.dd,sn,S\*cc<cr><lf>

### Format description

- 1 **I** = ID for sensor unit, default set to 5
- 2 **hhmmss.ss** = Time of position hour, minutes, seconds (local SpotTrack time — time since last boot)
- 3 **nn** = Number of reflectors reported to DP
- 4 **ss** = Sequence number (multiple reflectors), range 0 – (number of reflectors reported to DP –1)
- 5 **id** = Reflector DP ID
- 6 **rrrr.rr** = Horizontal distance in meters, decimal centimetres
- 7 **aa.a** = Horizontal distance accuracy estimate. Set fixed to 0.1
- 8 **bbb.bb** = Bearing to reflector 0.00 to 359.99 degrees
- 9 **ss.ss** = Bearing accuracy estimate. Set fixed to 0.05
- 10 **±vv.vv** = Vertical angle to reflector (-90.0 - +90.0), the + sign is omitted when positive
- 11 **ff.f** = Vertical angle accuracy estimate. Set fixed to 1.0
- 12 **±dd.dd** = Not used
- 13 **sn** = Not used
- 14 **S** = 9 – Valid Status
- 15 **\*cc** = Computed checksum
- 16 **<cr>** = Carriage return
- 17 **<lf>** = Line feed

### Example 3 PSXRAD message

\$PSXRAD,5,000516.27,2,0,1,70.80,0.1,14.87,0.1,0.41,0.1,0.00,0,9\*05

\$PSXRAD,5,000516.27,2,1,2,260.10,0.1,58.97,0.1,-2.29,0.1,0.00,0,9\*15

## Fanbeam MDL message

Standard telegram with checksum.

### Format

nn rrrr.rr bbb.bb cc<cr><lf>

### Format description

- 1 **nn** = Reflector DP ID
- 2 **rrrr.rr** = Horizontal distance in meters, decimal centimetres
- 3 **bbb.bb** = Bearing to reflector 000.00 to 359.99 degrees
- 4 **cc** = Computed checksum
- 5 **<cr>** = Carriage return



6 <lf> = Line feed

*Example 4 Fanbeam MDL message*

01 0070.80 014.87 14

02 0260.10 058.97 14

## Fanbeam MDL message without checksum

Standard telegram without checksum.

### Format

nn rrrr.rr bbb.bb <cr><lf>

### Format description

- 1 nn = Reflector DP ID
- 2 rrrr.rr = Horizontal distance in metres, decimal centimetres
- 3 bbb.bb = Bearing to reflector 000.00 to 359.99 degrees
- 4 cr = Carriage return
- 5 lf = Line feed

*Example 5 Fanbeam MDL message without checksum*

01 0070.80 014.87

02 0260.10 058.97

## CyScan Kongsberg message

### Format

\$PGNKM, n, rrrr.rr, a.a, bbb.bb, s.ss, SS\*cc<cr><lf>

### Format description

- 1 n = Reflector DP ID
- 2 rrrr.rr = Horizontal distance in meters, decimal centimetres
- 3 a.a = Distance accuracy estimate. Set fixed to 0.1
- 4 bbb.bb = Bearing to reflector 000.00 to 359.99 degrees
- 5 s.ss = Bearing accuracy estimate. Set fixed to 0.05
- 6 SS = 09 – Valid Status
- 7 \*cc = Computed checksum
- 8 <cr> = Carriage return
- 9 <lf> = Line feed

*Example 6 CyScan Kongsberg message*

\$PGNKM,1,0156.89,0.1,028.23,0.05,09\*61

\$PGNKM,2,0906.41,0.1,079.25,0.05,09\*67

## Detailed interface descriptions

### RS-422 A and B signal definition

According to the following standard the signal state definitions are:

- IEC 61162-1. The idle, marking, logical 1, OFF or stop bit states are defined by a negative voltage on line A with respect to line B. The active, spacing, logical 0, ON or start bit states are defined by a positive voltage on line A with respect to line B. It should be noted that the above A with respect to B levels are inverted from the voltage input/output requirements of standard UARTs and that many line drivers and receivers provide a logic inversion.

With reference to the table showing the pin layout for the serial ports on the rear panel screw terminals, note that the separate GND (ground) pin for each port is isolated from the chassis and shall act as a common signal intended to be connected between the talker (-TX) and the listener side (RX) of other equipment, for example the corresponding isolated GND (ground) pin or common pin. The purpose of the common signal is to increase the reliability of the hardware transmission. It must not be connected to the chassis or the cable screen. This applies to both sides of a connection. The cable screen shall be connected to the equipment chassis on one side only, preferably talker side, -TX.

### COM 1 and COM 2

COM 1 and COM 2 at the rear of the Processing Unit are 9-pin DSub male and have the following pin layout.

Pin no.	RS-232	Pin no.	RS-232
1	DCD1	6	DSR1
2	RXD1	7	RTS1
3	TXD1	8	CTS1
4	DTR1	9	RI1
5	GND		

#### Note


---

*COM 1 and 2 are not as accurate with regard to timing as COM 9 to 14 and are not recommended used for timing critical outputs.*

---

## Connector board

The illustration shows the screw terminal pin layout on the connector board at the rear of the Control Unit.



## Serial lines

This system communicates with external equipment through the RS-422 serial input and output lines.

*Table 1 Pin layout of serial input/output lines*

Pin no.	RS-422 signal
1	RX_A
2	RX_B
3	GND isolated
4	TX_A
5	TX_B

## Ethernet connection

The Control Unit has the possibility to input and output data on individually configurable network ports. The format and update rate are configured for each port in the **SpotCore Configuration** view.

- **LAN 1 in the front.** This is a service port and has less capacity (10/100 Mbps) than the other LANs. For direct connection to a PC you might need a crossover cable instead of a straight-through cable. The pin wiring for the different cable configurations is according to the table.

Straight-through		Crossover			
Signal	Pin no.	Signal	Pin no.	Pin no.	Signal
TX+	1	TX+	1	3	RX+
TX-	2	TX-	2	6	RX-
RX+	3	RX+	3	1	TX+
RX-	6	RX-	6	2	TX-

Note

*The pins 4, 5, 7 and 8 are not used.*

- **LAN 2, 3 and 4 at the rear.** These local area networks (LAN) are of high capacity (10/100/1000 Mbps) and are of type auto crossover and auto-negotiation. Below is the pin wiring for these LANs connected to different network capacities:

10/1000 or 100/1000 Mbps Ethernet			1000/1000 Mbps Ethernet		
Pin no.	Signal	Description	Pin no.	Signal	Description
1	TX_DA+	Transceive data +	1	BI_DA+	Bi-directional pair +A
2	TX_DA-	Transceive data -	2	BI_DA-	Bi-directional pair -A
3	RX_DB+	Receive data +	3	BI_DB+	Bi-directional pair +B
4			4	BI_DC+	Bi-directional pair +C
5			5	BI_DC-	Bi-directional pair -C
6	RX_DB-	Receive data -	6	BI_DB-	Bi-directional pair -B
7			7	BI_DD+	Bi-directional pair +D
8			8	BI_DD-	Bi-directional pair -D

To connect the unit network, use twisted pair (TP) cable with RJ-45 connectors. To comply with the IEC 60945 standard, shielded (screened) cable has to be used. Recommended cable type is CAT-5e. Category 5e cable is an enhanced version of Category 5 that adheres to more stringent standards. It is capable of transmitting data at speeds of up to 1000 Mbps (1 Gigabit per second). The maximum length of the cable which can be used is 100 metres (328 ft).

# EU conformity declaration



KONGSBERG

## EU DECLARATION OF CONFORMITY

Manufacturer's name: **Kongsberg Seatex AS**

Manufacturer's address: **Havnegata 9, N-7010 Trondheim, Norway**

declares that the product:

Product: **SpotTrack**

Product items: 

- **Spot-E-Sensor**
- **Spot-E-JBF**

is in conformity with the **EMC directive 2014/30/EU** and **Low Voltage Directive 2014/35/EU**,

using relevant sections of the following product standards:

EMC: **IEC/EN 60945: 2002**

Electrical safety: **IEC/EN 61010-1:2010**

### Test references

EMC report: E13276.00; issued by Nemko AS.

Safety reports:


- Report: KSX-2014-2-Spot; issued by Kongsberg Seatex AS
- Report Number: MTK5P06816-1rev1; issued by SP Technical Research Institute of Sweden.

Further, the product is compliant to RoHS Directive **2011/65/EU** with reference to standard **EN 50581:2012**.

### Supplementary information

The product was tested in its normal configuration.

Date and signature  
2018-07-05

  
Arne Rinnan, CTO

# Equipment handling

## Inspection

Carry out an inspection of the equipment immediately after the units have arrived at their destination. Check for physical damage, water intrusion or other mishandling.

Should there be any damage to the equipment, please notify the manufacturer immediately. Refer to on page for contact information.

## Sensor Unit handling

The Sensor Unit is a delicate instrument and must be handled with care.

The Sensor Unit is shipped in a specially designed transportation container. Keep the Sensor Unit within the container until everything is ready for installation of the unit in the mounting bracket. Keep the sensor protection cover in place until the sensor has been mounted.

### Note

---

*After the installation, please save the transportation container. The Sensor Unit must be shipped in this container for service or repair to maintain the warranty.*

---

It is recommended to keep the protection cover over the Sensor Unit when the unit is not in use.

## Safety

Operation or troubleshooting of this equipment will not imply any risk for high voltages, explosions or exposure to gas. The equipment complies with IEC 61010-1/EN 61010-1 standards regarding product safety and IEC 60945/EN 60945 standards on electromagnetic compatibility (immunity/radiation) and vibration.

## Disposal

All electrical and electronic components have to be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or local authorities. The correct disposal and separate collection of your old appliance will help prevent potential negative consequences for the environment and human health. It is a precondition for reuse and recycling of used electrical and electronic equipment. For more detailed information about disposal of your old appliance, please contact your local authorities or waste disposal service.

The equipment may be returned to Kongsberg Seatex AS if there is no local WEEE (Waste Electrical and Electronic Equipment) collection. The equipment is marked with this pictogram.



# References

## **Reference documents**

- 1 *SpotTrack Operator manual*, Kongsberg Seatex AS
- 2 *MRU Installation manual*, Kongsberg Seatex AS



**A**

about this manual, 7  
 accessories, description, 11  
 additional parts, 13  
 automatic logging, 59

**B**

blind zone, 49

**C**

cable layout, 45  
 cable list, Fanbeam, 45  
 cable plan, 45  
 cable plan, Fanbeam, 45  
 cable specifications, 75  
 cables, 27, 37  
 cabling, 27  
 cabling, Control Unit, 37  
 cabling, Control Unit to DP, 37  
 cabling, ground, 29  
 cabling, junction box (field) to Fanbeam power supply, 28  
 cabling, junction box (field) to junction box (inhouse Fanbeam), 29  
 cabling, junction box (inhouse) to Control Unit, 29, 37  
 cabling, junction box to ground, 29  
 cabling, Sensor Unit to junction box (field), 27  
 changing log length, 59  
 checking system functionality, 57  
 Class 1 laser, 13  
 Class 1 laser product, 14  
 Class 3R, 13–14  
 cleaning kit, 12  
 COM ports, 80  
 communication type, 51  
 compass safe distance, specification, 76  
 configuration, 47  
 configuration parameters, how to select, 47  
 conformity declaration, 83  
 connection, Control Unit to sensor, 55  
 connector board, pin layout, 81  
 contact details, 15  
 Control Unit dimensions, 66, 73

Control Unit interfaces, 76  
 Control Unit location, 18  
 Control Unit power, 74  
 Control Unit safety, 76  
 Control Unit, cabling, 37  
 Control Unit, description, 10  
 Control Unit, environmental, 74  
 Control Unit, how to connect to sensor, 55  
 Control Unit, how to install, 34  
 Control Unit, how to install in the rack, 34  
 Control Unit, how to set up remote connection, 56  
 Control Unit, rear interfaces, 36  
 CyScan Kongsberg message, 79

**D**

data communication, how to verify, 57  
 defining vessel dimensions, 57  
 description, accessories, 11  
 description, Control Unit, 10  
 description, junction box (field), 10  
 description, junction box (inhouse), 10  
 description, Processing Unit, 10  
 description, Sensor Unit, 10  
 dimensions, 72  
 dimensions, Control Unit, 66, 73  
 dimensions, junction box (field Fanbeam type), 64  
 dimensions, junction box (field), 73  
 dimensions, junction box (inhouse), 65, 73  
 dimensions, mounting bracket, 62  
 dimensions, prism cluster, 67  
 dimensions, Sensor Unit, 61, 72  
 dimensions, single prism holder, 69  
 disabling MRU readings, 52  
 display keypad, 52  
 display, how to set up, 52  
 displaying keypad, 47  
 displaying raw sensor data, 57  
 disposal of electrical components, 85

DP interface, how to set up, 51  
 drawings, 60  
 drawings, installation, 16

**E**

editing in text boxes, 47  
 enabling MRU readings, 52  
 entering MMSI, 56  
 environmental specifications, 74  
 environmental specifications, Processing Unit, 74  
 environmental, Control Unit, 74  
 environmental, junction box, 75  
 environmental, Sensor Unit, 74  
 equipment, 16  
 equipment handling, 84  
 equipment inspection, 84  
 Ethernet cable, 75  
 ethernet connection, 81  
 EU conformity declaration, 83  
 external interfaces, 76  
 eye-safe, 13

**F**

Fanbeam MDL message, 78  
 Fanbeam MDL message, no checksum, 79  
 Fanbeam replacement, system diagram, 8  
 front interfaces, 35  
 front interfaces Control Unit, 35

**G**

ground, 29  
 guarantee, restrictions, 13

**H**

handling, Sensor Unit, 84  
 health and safety, 84  
 how to set, blind zone for mounting bracket, 49  
 how to, change log length, 59  
 how to, check sensor product and software version, 58  
 how to, check sensor serial number, 58

- how to, check system functionality, 57
- how to, connect Control Unit to sensor, 55
- how to, define vessel dimensions, 57
- how to, display keypad, 47
- how to, display raw sensor data, 57
- how to, dispose of electrical components, 85
- how to, edit in text boxes, 47
- how to, enter MMSI, 56
- how to, install main unit in rack, 34
- how to, install prism cluster, 32
- how to, install Processing Unit in rack, 34
- how to, install single prism, 30
- how to, install the Control Unit, 34
- how to, install the Control Unit in the rack, 34
- how to, install the horizontal mounting bracket, 22
- how to, install the junction box, 26
- how to, install the junction box (field), 24
- how to, install the Sensor Unit, 22, 26
- how to, interface to MRU, 41
- how to, measure mounting bracket location, 21
- how to, measure mounting bracket orientation, 20
- how to, move the sensor, 58
- how to, replace the sensor, 58
- how to, select configuration parameters, 47
- how to, select measurement type, 53
- how to, select measurement unit, 53
- how to, select vessel orientation, 52
- how to, set location for mounting bracket, 48
- how to, set orientation for mounting bracket, 48
- how to, set sensor search area, 50
- how to, set survey origin, 48
- how to, set up Control Unit for remote connection, 56

- how to, set up DP interface, 51
- how to, set up for 4th generation MRU, 41
- how to, set up for 5th generation MRU, 42
- how to, set up sensor IP address, 54
- how to, set up the display, 52
- how to, set up the MRU, 52
- how to, set up the network, 54
- how to, set vessel shape and dimensions, 56
- how to, verify data communication, 57

## I

- installation drawings, 16
- installation, Control Unit, 34
- installation, Control Unit in cabinet, 34
- installation, horizontal mounting bracket, 22
- installation, junction box, 24, 26
- installation, junction box (inhouse), 26
- installation, monitor, 39
- installation, Sensor Unit, Fanbeam, 22
- installation, touch screen monitor, 39
- installing prism cluster, 32
- installing single prism, 30
- installing, main unit in rack, 34
- installing, Processing Unit in rack, 34
- interconnections, 45
- interface descriptions, 80
- interfaces, Control Unit, 35, 76
- interfaces, external, 76
- interfaces, front Control Unit, 35
- interfaces, Sensor Unit, 76
- interfacing to MRU, 41
- IP address for sensor, how to set up, 54

## J

- junction box (field Fanbeam type), dimensions, 64
- junction box (field Fanbeam), location, 17

- junction box (field) dimensions, 73
- junction box (field) power, 74
- junction box (field), description, 10
- junction box (inhouse) dimensions, 73
- junction box (inhouse) power, 74
- junction box (inhouse), description, 10
- junction box (inhouse), dimensions, 65
- junction box (inhouse), how to install, 26
- junction box (inhouse), location, 18
- junction box, environmental, 75
- junction box, how to install, 24, 26

## K

- keypad, enable or disable, 52
- keypad, how to display, 47

## L

- labels, 14
- LAN 1, 81
- LAN 2, 82
- LAN 3, 82
- LAN 4, 82
- LCD display, 35
- LED, 35
- LED indications Control Unit, 35
- location, Control Unit, 18
- location, junction box (field Fanbeam), 17
- location, junction box (inhouse), 18
- location, monitor, 18
- location, mounting bracket, 48
- location, reflectors, 19
- location, Sensor Unit, 17
- location, units, 17
- log length, how to change, 59
- logging, automatic, 59

## M

- main unit, how to install in rack, 34
- maintenance, 7
- maximum number of reflectors, setup, 51

- measurement type , how to select, 53
- measurement unit, how to select, 53
- measuring mounting bracket location, 21
- measuring mounting bracket orientation, 20
- message types, 77
- MMSI, how to enter, 56
- monitor installation, 39
- monitor location, 18
- monitor resolution, 9
- mounting bracket blind zone, how to set, 49
- mounting bracket dimensions, 62
- mounting bracket location, how to measure, 21
- mounting bracket orientation, how to measure, 20
- mounting bracket reference point, 19
- mounting bracket, how to install, 22
- mounting bracket, how to set location, 48
- mounting bracket, how to set orientation, 48
- mouse, 9
- moving the sensor, 58
- MRU 4th generation, how to set up, 41
- MRU 5th generation, how to set up, 42
- MRU data, 52
- MRU, how to interface, 41
- MRU, how to setup, 52
- N**
- network, how to set up, 54
- O**
- orientation pin, 19, 22
- orientation, mounting bracket, 48
- P**
- parts, additional, 13
- performance, Sensor Unit, 72
- pin layout COM ports, 80
- pin layout connector board, 81
- power, 73
- power and Ethernet cable, 75
- power cable, 75
- power specifications, Processing Unit, 74
- power, Control Unit, 74
- power, junction box (field), 74
- power, junction box (inhouse), 74
- power, Sensor Unit, 73
- pre-installation, 16
- prism cluster, dimensions, 67
- prism cluster, how to install, 32
- prism holder, dimensions, 69
- prism, how to install, 30
- Processing Unit, description, 10
- Processing Unit, environmental specifications, 74
- Processing Unit, how to install in rack, 34
- Processing Unit, power specifications, 74
- product labels, 14
- product restrictions, 13
- product version, how to check, 58
- protection cover, 11
- protection cover, Sensor Unit, 16, 84
- PSXRAD message, 77
- R**
- rack requirements, 21
- raw data, how to display, 57
- rear interfaces, 36
- rear interfaces, Control Unit, 36
- reference documents, 86
- reference point, mounting bracket, 19
- reflector, how to install, 30
- reflectors, how to install, 32
- reflectors, location, 19
- remote connection, Control Unit, 56
- replacing the sensor, 58
- requirements for rack, 21
- resolution, monitor, 9
- restrictions, guarantee, 13
- RS-422 signal, 80
- S**
- safety, 76, 84
- safety regulations, 13
- safety, Control Unit, 76
- safety, Sensor Unit, 76
- scope of supply, 12
- selecting configuration parameters, 47
- selecting measurement type, 53
- selecting measurement unit, 53
- selecting vessel orientation, 52
- sensor search area , how to set, 50
- Sensor Unit dimensions, 61, 72
- Sensor Unit environmental, 74
- Sensor Unit handling, 84
- Sensor Unit interfaces, 76
- Sensor Unit power, 73
- Sensor Unit protection cover, 16, 84
- Sensor Unit safety, 76
- Sensor Unit, description, 10
- Sensor Unit, how to install, 22
- Sensor Unit, location, 17
- Sensor Unit, performance, 72
- sensor, how to move/replace, 58
- serial cable, 75
- serial line, DP, 37
- serial lines, 81
- serial number, how to check, 58
- set up maximum number of reflectors, 51
- setting survey origin, 48
- setting up DP interface, 51
- setting up MRU port, 52
- setting up sensor IP address, 54
- setting up the display, 52
- setting up the network, 54
- setting vessel shape and dimensions, 56
- setting, blind zone for mounting bracket, 49
- setting, sensor search area, 50
- settings, MRU 4th generation, 41
- settings, MRU 5th generation, 42
- single prism holder, dimensions, 69
- single prism, how to install, 30
- skills, 16
- software version, 58
- specification, compass safe distance, 76
- specifications, 72
- specifications, cables, 75
- SpotTrack message, 77

- standard parts, 12
- support information, 15
- survey origin, how to set, 48
- system description, 8
- system diagram, Fanbeam replacement, 8
- system functionality, how to check, 57
- System menu, 47
- system units, 10

### T

- technical specifications, 72
- telegram, 51
- telegrams, 77
- text box, how to edit, 47
- tools, 16
- touch screen monitor installation, 39
- transportation box, 11

### V

- verifying data communication, 57
- vessel dimensions, how to define, 57
- vessel dimensions, how to set, 56
- vessel orientation, how to select, 52
- vessel shape, how to set, 56
- VGA cable, 76

### W

- warranty, 16, 84
- where to, place the Control Unit, 18
- where to, place the junction box (field Fanbeam), 17
- where to, place the junction box (inhouse), 18
- where to, place the monitor, 18
- where to, place the reflectors, 19
- where to, place the Sensor Unit, 17



©2021 Kongsberg Seatex